
TERRACE FLOOR
12TH FLOOR LVL.
11TH FLOOR LVL.
10TH FLOOR LVL.
9TH FLOOR LVL.
8TH FLOOR LVL.
7TH FLOOR LVL.
6TH FLOOR LVL.
5TH FLOOR LVL.
4TH FLOOR LVL.
3RD FLOOR LVL.
2ND FLOOR LVL.
1ST FLOOR LVL.
GR. FLOOR LVL.
GR.FLOOR LVL.
3050
3050
3050